



Installation Instructions

1. The top of the standoff plates must be flush with the top surface or lower.
2. Hold the standoff plates at the desired position (refer to the glass for proper spacing) and mark the installation holes.
3. Drill the holes and mount the standoff plates with appropriate fasteners (not included).
4. Using gaskets and grommets for protection, hold the glass against the standoffs and secure with the standoff caps.

 <p>Quality Enclosures <small>America's Shower Door</small></p>
FA-STANDOFFS-PLATE
Fascia (Standoffs-Plate) Glass Shield