



Installation Instructions

1. Place the base shoe in the desired position and mark the installation holes.
2. Drill the holes and mount the base shoe with appropriate fasteners (not included).
3. Place the black wedges at approximately 12" intervals in the base shoe, and set the glass on top of the wedges.
4. Position the isolators on the other side of the glass opposite the wedges, and tighten the socket head screws at the top of the isolators to secure the glass.
5. Push the rubber gaskets against the base shoe and glass on both sides.
6. Secure the end caps to the base shoe with epoxy (not included).



SU-TRACK-HD

Surface (Track-Heavy Duty) Glass Shield