



Installation Instructions

1. The bottom of the clamps must be 7-1/4" below the top surface or lower.
2. Hold the clamps at the desired position (refer to the glass for proper spacing) and mark the installation holes.
3. Drill the holes and mount the clamps with appropriate fasteners (not included).
4. Using gaskets, grommets, and setting blocks for protection, set the glass on the clamp bases and secure with the supplied screws through the cover plates.



FA-CLAMPS-LD

Fascia (Clamps-Light Duty) Glass Shield