


Installation Instructions

1. The center of the upper standoffs must be 2" below the top surface or lower.
2. Hold the standoffs at the desired position (refer to the glass for proper spacing) and mark the installation holes.
3. Drill the holes and mount the standoffs with appropriate fasteners (not included).
4. Using gaskets and grommets for protection, hold the glass against the standoffs and secure with the standoff caps.


FA-STANDOFFS-2X1.75
Fascia (Standoffs-2 x 1.75) Glass Shield